CONTROLS

Operator controls are on the front right of the steamer.

- The DRAIN handle controls the manual drain valve. In the horizontal position the drain is open and in the downward vertical position the drain is closed.
- The ON/OFF power switch starts the steamer, fills it with water and heats it so that it is ready for use. It also shuts the steamer OFF.

TURN ON PROCEDURE

- Close the DRAIN valve.
- 2. Press the ON/OFF switch to ON.

The steam generating reservoir will fill and the timer will show when the steamer is ready for use, in approximately 10-15 minutes.

3. Load food into pans or carriers.

Pans should be filled to about the same levels and should be even on top.

- 4. Open the door and slide the pans or carriers onto the supports.
- 5. Close the door and set the MERIDIAN™ timer.
- 6. When the MERIDIAN™ timer signals DONE, open the door and remove the pans from the steamer.

Use hot pads or oven mitts to protect your hands from hot pans or carriers.

SHUT-DOWN PROCEDURE

- 1. Press the ON/OFF switch to OFF.
- 2. Open the DRAIN valve.
- 3. Open the steamer door and let it cool.
- 4. Clean the steamer and empty the drain pan following the local store operating procedure.